



REFER TO PELICAN Z8 INSTALLATION  
GUIDES FOR CONTROL TERMINAL WIRING  
AND SEQUENCE GUIDE

REFER TO PELICAN Z8 INSTALLATION  
GUIDE FOR WIRELESS ANTENNA  
PLACEMENT AND WIRING

**AHU w/ AC Only, Bypass Damper, and Economizer**

DRAWN BY



CHECKED

DATE

**02/18/2016**

SCALE

**NTA**

SHEET NO.

**1 of 1**