



REFER TO PELICAN Z8 INSTALLATION GUIDES FOR CONTROL TERMINAL WIRING AND SEQUENCE GUIDE

REFER TO PELICAN Z8 INSTALLATION GUIDE FOR WIRELESS ANTENNA PLACEMENT AND WIRING

**AHU w/ AC Only, Variable Speed Fan, and Economizer
Boiler for Zone Reheat**

DRAWN BY



CHECKED

DATE

02/18/2016

SCALE

NTA

SHEET NO.

1 of 1